



Scan for
Putting Arc
Home Page



Scan for original
Putting Arc Video

Folding Arc Mirror

Instructions for Use

The Folding Arc Mirror is a new product that solves the dual problem of (1) how to use a T3 Putting Arc indoors, and (2) how to accurately monitor head, eye, shoulder positions and head/body stability while practicing with a T3 or any Putting Arc indoors or outdoors.

Up to now the T3 **has not** been recommended for indoor use. The Folding Arc Mirror creates a very stable system by combining the Velcro fasteners with the mirror and T3. This can be used outdoors as well as indoors in a home or hotel room.


The Folding Arc Mirror was designed to work with the T3 Putting Arc but it will work equally as well with any of the other Putting Arcs. It has a large usable size, yet folds to fit in a golf bag or suitcase for easy travel.



Folding Arc Mirror with T3




Folding Arc Mirror with
Original Deluxe and Putting Track



Folding Arc Mirror with MS 3D




Folding Arc Mirror with MS III



Folding Arc Mirror in bag

Quick Start - 1. Place Folding Arc Mirror on a putting surface with the Aim Point Line pointing to the Aim Point (see back of this page for terminology) 2. Place Putting Arc on Mirror as shown above 3. Place back of ball even with Putter Face Line as shown in picture 5 above. 4. Center putter head on Aim Point Line, align face of putter with Putter Face Line and putt ball toward Aim Point. Keep the heel of the putter against the Putting Arc and the putter face square to the Putting Arc where it touches the Arc. Do this half of the time and the other half, try to do the same thing while maintaining 1/4" gap between the heel of the putter and the Putting Arc.

Top View Folding Arc Mirror



Description:

- The $\frac{1}{4}$ " holes in the mirror allow the mirror to be anchored on an outdoor green with golf tees.
- The thin hinge on the bottom side of the mirror allows the mirror to be folded so it is small enough to fit in the side pocket of a golf bag. The small size and light weight make it very easy for the golfer who travels a lot. When the mirror is unfolded, the golfer has a large 12" x 10" mirror and can monitor most body positions and alignments without moving the mirror.
- The unique L-Shaped design of the Folding Arc Mirror allows the golf ball to sit on the green or putting surface for a realistic feel at impact. When the mirror is unfolded and placed on a green or indoor carpet, the balls can then be efficiently placed in the correct position and putt. As shown in the drawing and pictures, these balls can be easily moved into position with the putter and without bending over or hand placement.
- The single Putter Face Line on the mirror is for a correct, square putter face alignment at setup. The Ball/Aim Point Line on the mirror should always be pointed at the Aim Point for perfect Putting Arc alignment.
- The Hinge Line and the Bottom Edge Line on the large mirror are used to make sure the combination of Folding Arc Mirror and Putting Arc is parallel to the intended starting line of the putt, or the Ball/Aim Point Line.
- Additional custom lines can be drawn on the mirrors by the golfer using a Sharpie marking pen.
- The attractive black cloth bag is used to protect the Folding Arc Mirror during travel and storage.
- The Folding Arc Mirror can be used with or without a Putting Arc. A golfer can use the Putting Arc he/she already has, or order one separately. A Putting Arc **does not** come with the Folding Arc Mirror.
- The Velcro Kit is used is used to securely attach a Putting Arc to the mirror with infinite adjustability, and to make sure the Putting Arc mirror combination moves with the mirror when it is adjusted. The Velcro adjustment is necessary because the putter head length can vary from under 4" to well over 5", so the center-line to heel distance can vary up to 1".
- The Putting Arc is correctly attached when (1) the sweet spot or line-up line on the putter is centered on the Ball/Aim Point Line on the small mirror, (2) the heel of the putter is in contact with the Putting Arc, (3) the straight edge of the Putting Arc is parallel to the edge of the mirror and (4) the center line of the Putting Arc is lined up with the Putter Face Line on the Folding Arc Mirror. The back of the ball should always be even with this line for proper use of the Putting Arc. Thus, any line-up adjustments to the mat and mirror will automatically adjust the Putting Arc and it will always be correctly aligned.